
























	Stoßdämpfer • shock absorbers • amortisseurs • Amortiguadores • Ammortizzatori							
	i	mm						
			comfort	sport	comfort	sport		
		0-20		59520		59520		
	30-50		59440	59460		59440	59460	
	60-100		59580	58290		59580	58290	

	Büchensätze • bushing kit • kit SilentBlocs • kits de silenblocs • kit boccole per balestre					
	i					
						
		13641	13647			

	Bridensatz • U-Bolt Kit • kit étriers • kits de abarcones • kit cavallotti				
	i				
		15854		15769	
				mm	

	Lenkungs­dämpfer • steering stabilizer • amortisseur de direction • amortiguador de dirección • ammortizzatore di sterzo					
	i					
						
		66042				