
























	Stoßdämpfer • shock absorbers • amortisseurs • Amortiguadores • Ammortizzatori							
	i	mm						
			comfort	sport	comfort	sport		
		0-30		59650			59490	
		40-60		57700		58710		

	Höherlegungsfahrwerke • suspension lift kits • ensemble rehausse de suspension • kit de elevacion de suspensión • Asseto Rialzato									
	i	mm	TÜV							
						2	57700		2	58710
		+50	D	o.k.	S27229	1	16735		2	77106

	Büchensätze • bushing kit • kit SilentBlocs • kits de silenblocs • kit boccole per balestre					
	i					
						
			13653			

	Bridensatz • U-Bolt Kit • kit étriers • kits de abarcones • kit cavallotti				
	i				
				15817	

	Blattfedern • leaf springs • ressorts à lames • Ballestas • Balestre				
	i				
			mm		mm
				77106	