

























	Stoßdämpfer • shock absorbers • amortisseurs • Amortiguadores • Ammortizzatori							
	i	mm						
			comfort	sport	comfort	sport		
		0-40		58500		58450		
		50-60		58500		58450		

	Höherlegungsfahrwerke • suspension lift kits • ensemble rehausse de suspension • kit de elevacion de suspensión • Asseto Rialzato									
	i	mm	TÜV							
						2	58500		2	58450
	+30/70	D	o.k.	S10219	 <td>1</td> <td>16775</td> <td> <td>2</td> <td>77103</td> </td>	1	16775	 <td>2</td> <td>77103</td>	2	77103

	Büchensätze • bushing kit • kit SilentBlocs • kits de silenblocs • kit boccole per balestre						
	i						
							
			13655				

	Bridensatz • U-Bolt Kit • kit étriers • kits de abarcones • kit cavallotti					
	i					mm
				15842		

	Blattfedern • leaf springs • ressorts à lames • Ballestas • Balestre					
	i					mm
				77103	+70	