





















	Stoßdämpfer • shock absorbers • amortisseurs • Amortiguadores • Ammortizzatori							
		mm						
				comfort	sport		comfort	sport
		0-20			57420		58890	59860
		30-60			57700		58890	59860

	Büchensätze • bushing kit • kit SilentBlocs • kits de silenblocs • kit boccole per balestre					
						
						
		tmi springs only	13654			

	Bridensatz • U-Bolt Kit • kit étriers • kits de abarcones • kit cavallotti				
					mm
				15793	

	Blattfedern • leaf springs • ressorts à lames • Ballestas • Balestre				
			mm		mm
					77150