















	Stoßdämpfer • shock absorbers • amortisseurs • Amortiguadores • Ammortizzatori							
	i	mm						
			comfort	sport	comfort	sport		
		0-20		57410		58450		
	30-60		58500		58510			

	Büchensätze • bushing kit • kit SilentBlocs • kits de silenblocs • kit boccole per balestre					
	i	  			 	
		tmi springs only	13654			

	Bridensatz • U-Bolt Kit • kit étriers • kits de abarcones • kit cavallotti					
	i					mm
				15793		

	Blattfedern • leaf springs • ressorts à lames • Ballestas • Balestre					
	i					mm
				77150		
					+50	