
















	Stoßdämpfer • shock absorbers • amortisseurs • Amortiguadores • Ammortizzatori						
	i	mm					
			comfort	sport	comfort	sport	
		0-30		59510	r	59610	
					l	59560	
		40-70			 r	58740	
					 l	58530	
		80-110			 r	58220	
					 l	58740	

	Büchsenätze • bushing kit • kit SilentBlocs • kits de silenblocs • kit boccole per balestre					
	i					
						
			13659			

	Bridensatz • U-Bolt Kit • kit étriers • kits de abarcones • kit cavallotti				
	i				mm
				15832	